





FIG.12A



TOUCH

FIG.12B



PRESS

FIG.12C

CANCEL

PUT YOUR CASH OR CARD INTO THE MACHINE

TICKET	TO OGIKUBO
AMOUNT OF PURCHASE MONEY	¥160
AMOUNT OF MONEY PUT INTO THE MACHINE	¥0